
GATEWAY User Manual

GATEWAY G2

Model: 70mm x 70mm x 26mm Dimensions: Network: IEEE standard: 802.11 b/g/n Power interface : Type-C USB DC 5V/500mA Power input:

Light Status




WiFi 2.4G



Pair the Gateway with APP

3) Select [Gateway]





▲ Notice: If times out, please power off and try it again.

Limited Warranty

1.For any defect in material and workmanship, the original purchaser of the product 1)Can return or ask for a replacement within 7 invoice days. 2)Can ask for a replacement within 15 invoice days. 3)Can ask for free repair in 365 invoice days. 2. This warranty does not cover defects caused by modifica

tion, alteration, misuse or physical abuse of the product.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines,

This equipment should be installed and operated with

minimum distance of 20cm the radiator your body. This

device and its antenna(s) must not be co-located or opera-

tion in conjunction with any other antenna or transmitter